

## Notched Transom Set-Up.

Load the boat onto the trailer until the back of the boat's transom is Flush with the **Outside Bunks.**

