

## Tunnel or Catamaran Hulls.

Load the boat onto the trailer, lining up the center bunks until the back of the boat's transom is flush with the **back of the bunks.**

