

Extra Tall Reverse Winch Stand – For Boats With No Bow-eye.

Once you correctly load your boat onto the trailer (transom flush with bunking), attach stand so the roller or V-stop touches the boat and the winch is set so the winch strap is level with or slightly higher than the point where it attaches to the boat (deck cleat or lifting ring). The roller/V-stop height is adjustable. So if there is a certain spot on the boat where the stop should hit, you can adjust the roller/V-stop.

