

Two Piece Bow Stop/Winch Stands

Once you correctly load your boat onto the trailer (transom flush with bunking), just attach the roller stand where it touches the boat. Make sure the winch is set so the winch strap is level with or slightly higher than to where the winch strap attaches (bow-eye or deck cleat).

